

# Simplicity Collection

## Simplified Installation Instructions

Instructions for interlocking wood  
flooring with 2G Locking system



### Step 1:

For the first row, fold down short ends of adjoining planks.  
Continue for the entire row.



### Step 2:

For second & all subsequent rows, connect planks on long side by angling into the locking groove and fold down flat.



### Step 3:

For the next plank on the same row, interlock long side at an angle, then  
slide left against the previous plank, Fold down plank on the short side .



### Step 4:

Continue for entire row, and then start subsequent row as in step 2 and step 3.